List of storage features

1 Glove box

2 Auxiliary boxes (if equipped)

3 Bottle holders/door pockets

4 Cup holders

5 Console box

6 Under tray

CAUTION

■ **Items that should not be left in the storage spaces**

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

- Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

Glove box

The glove box can be opened by pressing the lock release button and locked and unlocked using the mechanical key.

1 Opens
2 Locks
3 Unlocks

Power back door main switch (if equipped)

The power back door main switch is located in the glove box. (→P. 67)

CAUTION

Caution while driving

Keep the glove box closed.
Injuries may result in the event of an accident or sudden braking.

Bottle holders/door pockets

▶ Front

The front door pockets can be opened and closed.

▶ Rear

⚠ CAUTION

■ **Caution while driving (front door pockets)**

Keep the door pockets closed.
Injuries may result in the event of an accident or sudden braking.

■ **Items unsuitable for the bottle holders**

Do not place anything other than bottles in the bottle holders.
Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury.

NOTICE

■ **When stowing a bottle**

Put the cap on before stowing the bottle. Do not place open bottles in the bottle holders. The contents may spill.

Cup holders

▶ Front (type A)

Press down and release the right side of the cup holder lid.

▶ Front (type B)

Press in and release the cup holder.

▶ Rear

Press down the button on the arm-rest.

---

n **Cup holder insert**

The cup holder insert may be removed for cleaning.

CAUTION

n **Items unsuitable for the cup holder**

Do not place anything other than cups or beverage cans in the cup holders. Even when the lid is closed, items must not be stored in the cup holders.
Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.

n **To prevent burns**

Put a lid on containers with hot liquids inside.

n **When not in use**

Keep the cup holders closed.
Injuries may result in the event of an accident or sudden braking.

Console box

Slide the armrest while pulling up the lever, and lift the armrest.

---

n Trays in the console box

▶ Upper tray/upper trays

The tray slides forward/backward and can be removed.

▶ Lower tray

The tray can be removed.

CAUTION

■ **Caution while driving**

Keep the console box closed.
Injuries may result in the event of an accident or sudden braking.

NOTICE

■ **Trays**

Do not insert items exceeding the height of the tray. Doing so may prevent opening and closing of the lid.

Auxiliary boxes

▶ Overhead

Press in the lid.

This box is useful for temporarily storing sunglasses and similar small items.

▶ Rear seat (if equipped)

Pull down the armrest.

Pull up the lever to release the lock and lift the armrest.

CAUTION

Caution while driving

Do not leave the auxiliary box open while driving.
Items stored in the auxiliary box may fall out and cause death or serious injury in case of an accident or sudden stop.

Under tray

 CAUTION

Items unsuitable for the under tray

Observe the following precautions when putting items in the under tray. Failure to do so may cause items to be thrown out of the tray in the event of sudden braking or steering. In these cases, the items may interfere with pedal operation or cause driver distraction, resulting in an accident.

- Do not store items in the tray that can easily shift or roll out.
- Do not stack items in the tray higher than the tray's edge.
- Do not put items in the tray that may protrude over the tray's edge.